

eCabinet Systems v6.0 –

Program and Data Paths/Directories

Due to the fact that Vista and Windows 7 don't like programs to write to the program files directory without administrative rights, the file locations for v6 have changed.

Program files that do not change (mainly exe's and dlls) are still kept in the "Program Files" directory structure.

The "UserData Directory" contains all your user created files. If you do a copy when you install, your cabinets, assemblies, hole patterns and other "user created" files will be copied to this new location.

Note: The original versions of your old files will remain in the "Program Files" directory structure whether you instructed the eCabinet Systems install to copy your old 5.2 data or not. (It's kind of like a build in backup.)

Ex: Cabinets, Assemblies, Hole Patterns, DXFs, Jobs, Tools, etc. Other files, like ini and mdb, are now kept in the "AppData Directory". The Materials directory is also in this directory.

OLD DEFAULT FILE LOCATION FOR V5

Program and User Files – XP/Vista/Windows7

- **32bit**
`c:\program files\thermwood\eCabinet Systems\`
- **64bit**
`c:\program files (x86)\thermwood\eCabinet Systems\`

NEW DEFAULT FILE LOCATIONS FOR V6

Program Files – XP/Vista/Windows7 (exe and dlls):

- **32bit**
`c:\program files\thermwood\eCabinet Systems\`
- **64bit**
`c:\program files (x86)\thermwood\eCabinet Systems\`

UserData Files (files created by user ex: cabinets, assemblies, patterns, etc)

XP:

`c:\Documents and Settings\All Users\Documents\Thermwood\eCabinet Systems\`

Vista/Windows7

`c:\users\Public\Documents\Thermwood\eCabinet Systems\`

AppData Files (files used by ecabinets in the background, also contains Materials folder):

XP:

`c:\Documents and Settings\All Users\Application Data\Thermwood\eCabinet Systems\`

Vista/Windows7:

`c:\ProgramData\Thermwood\eCabinet Systems\`